

PBY CATALINA

TECHNICAL NOTICE

On page 15, step 4 should read:



4. After installing the struts to the fuselage turn the airplane upside-down. Align the struts on the wing making sure that the strut rests on the wood sheeting, not the open wing structure. Carefully drill a 1/16" [1.6mm] hole in the **bottom** of the wing but ***do not drill through the top of the wing!***